

SPICER®



**Seal Tool Kit
Part# SPI401**


Spicer® Seal Installation Tool Kit

The Right Tools for the Job. Minimize unnecessary downtime and repair costs that come with improperly installed seals. Using the right tools and techniques for the job always help ensure your seal is properly installed and seated. This convenient, all-inclusive kit provides the right tools to help you ensure the job is done right the first time, and every time. It features an extensive collection of color-coded tools that can be used on the most common Dana Spicer models. Plus, it contains instructions that are comprehensive and easy to understand, so you can install with confidence!




Spicer® Seal Installation Tool Kit

Frustrated with downtime and lost productivity caused by improperly installed seals? This convenient, indispensable kit helps ensure you have the right tools to properly install and seat the seal in your Dana Spicer axle.




Seal Installation Tool Chart

| Tandem Axle Model | Tool Type | Input Seal | Output Seal | Pinion Seal |
|---|-----------|-------------|-------------|-------------|
| DS341, DS404, DS454, DS405, DSP40, DSP41, DSP44, DSH40, DSH44, DST40 | Driver | 126917 | 126917 | 126917 |
| | Insert | | 128706HX | |
| D40-156 | Driver | 126917 | 126917 | 126917 |
| | Insert | 10021493 | 10021494 | 10021492 |
| D40-155 | Driver | 126917 | 126917 | 126917 |
| | Insert | 10021492 | 10021495 | 10021492 |
| D40-170, D46-170, D50-170, D52-190, D60-190, D70-190, D52-590, D60-190 | Driver | 210749 | 131471 | 210749 |
| | Insert | 10095470 | | 10095470 |
| DS461, DS462, DS463, DS581, DS601, DD461, DD463, DD581, DD601, DT461, DT463, DT581, DT601, DP461, DP463, DP581, DC461, DC463 | Driver | 210749 | 210751 | 210749 |
| | Insert | 210750 | | |
| Single Axle Model | Tool Type | Pinion Seal | | |
| | Driver | 126917 | | |
| S12-110, S14-110, S14-111, S16-130, S17-140, S19-140 | Driver | 126917 | | |
| | | | | |
| S21-060B, 17060S, 19060S, 21060S, 22060S, 23060S | Driver | 126917 | | |
| | | | | |
| S23-070B, S21-170, S23-170, S26-170, S23-172, S21-190, S23-190, S26-190, S30-190, S30-590, S35-590, S21-175, S23-175, S26-175 | Driver | 210749 | | |
| | Insert | 10095470 | | |
| 23080T, 23082T, 26082T, 23130S, 23137S, 23105S | Driver | 210749 | | |
| | | | | |
| 19055T, 21060T, 23060T, 21065T, 23060T | Driver | 126917 | | |
| | | | | |



Driver Tool



Insert Tool

Tool Kit Contents



IMPORTANT: Spicer strongly recommends using seal installation tools when installing new drive axle seals. The use of proper tools ensures that the seal is square and installed without damage. Make sure to follow all notes and warnings; failure to follow specific instructions may result in personal injury and/or component damage.

Order Yours Today! Visit www.SpicerParts.com/Merchandise (general public), www.DanaAftermarket.com (dealer/distributor), or contact your Spicer parts representative.

Seal Tool Kit Part# SPI401



Dana Aftermarket Group

PO Box 1000 Maumee, Ohio 43537
Phone: 1.800.621.8084
Product information: SpicerParts.com
E-cat / parts locator: DanaAftermarket.com

Form # HAXL-SEALTOOLS-SS-72018
Copyright Dana Limited, 2018.
All rights reserved. Dana Limited.
Printed in U.S.A.

SPICER®

